

IMPORTANT




WIRING CONNECTION & INSTALLATION BEST PRACTICES



KEEP MODULES AWAY FROM HEAT SOURCES



MOUNT WITH LOGO FACING UP AND/OR OUT TO A SIDE




SOLDER WIRE TIPS BEFORE SECURING TO TERMINALS



TERMINALS SHOULD BE SNUG AND NOT OVER-TIGHTENED



PINOUTS AND DIMENSIONS



FOR CLARIFICATION AND ASSISTANCE TO YOUR SPECIFIC APPLICATION, OUR ENGINEERING TEAM WOULD BE GLAD TO ANSWER ALL YOUR QUESTIONS. INFO@NUUT.CA




IMPORTANT**WIRING CONNECTION & INSTALLATION BEST PRACTICES**

KEEP MODULES AWAY FROM HEAT SOURCES




MOUNT WITH LOGO FACING UP AND/OR OUT TO A SIDE




SOLDER WIRE TIPS BEFORE SECURING TO TERMINALS



TERMINALS SHOULD BE SNUG AND NOT OVER-TIGHTENED

**SPECIAL BUTTON/SWITCH FUNCTIONS**

AUTOMATED FLASH-TO-PASS
Quickly toggle the Headlight HI/LO switch



HAZARD LIGHTS LEFT HAND DRIVE MODEL
Activate RIGHT TURN SIGNAL, then push HORN BUTTON 3 times



HAZARD LIGHTS RIGHT HAND DRIVE MODEL
Activate LEFT TURN SIGNAL, then push HORN BUTTON 3 times



TURN SIGNAL LIGHT FLASH PATTERN SELECTION
Quickly push HORN BUTTON 4 times to select next pattern




- PATTERN
- 1 - single burst (default)
 - 2 - double burst
 - 3 - single, then double burst
 - 4 - variable blink speed using VARIABLE DIAL on MODULE side
 - 5 - single sequential (sequential lights required)
 - 6 - half, then full sequential (sequential lights required)

ENGINE ON + NEUTRAL ON CLUTCH ON +

ENGINE START

Hold down START BUTTON

Engine switch must be in ON POSITION + NEUTRAL or CLUTCH switch ON



BRAKE LIGHT AUTO HOLD

Activate by quickly pulsing the BRAKE LEVER/PEDAL 3 times
Once to deactivate.



BRAKE LIGHT FLASH PATTERN SELECTION (MODULE SIDE)

Press BUTTON on the side of the module to select next pattern

- PATTERN
- 1 - standard (default)
 - 2 - 4 flashes
 - 3 - 2 flashes

FOR CLARIFICATION AND ASSISTANCE TO YOUR SPECIFIC APPLICATION, OUR ENGINEERING TEAM WOULD BE GLAD TO ANSWER ALL YOUR QUESTIONS. INFO@NUUT.CA



IMPORTANT



WIRING CONNECTION & INSTALLATION BEST PRACTICES



KEEP MODULES AWAY FROM HEAT SOURCES



BEST




GOOD



WORST

MOUNT WITH LOGO FACING UP AND/OR OUT TO A SIDE




SOLDER WIRE TIPS BEFORE SECURING TO TERMINALS



TERMINALS SHOULD BE SNUG AND NOT OVER-TIGHTENED






INPUT







X-NET (LEFT)

X-NET (L) CONNECTOR



X-NET (RIGHT)

X-NET (R) CONNECTOR



FOR CLARIFICATION AND ASSISTANCE TO YOUR SPECIFIC APPLICATION, OUR ENGINEERING TEAM WOULD BE GLAD TO ANSWER ALL YOUR QUESTIONS. INFO@NUUT.CA



IMPORTANT




WIRING CONNECTION & INSTALLATION BEST PRACTICES



KEEP MODULES AWAY FROM HEAT SOURCES



MOUNT WITH LOGO FACING UP AND/OR OUT TO A SIDE




SOLDER WIRE TIPS BEFORE SECURING TO TERMINALS




TERMINALS SHOULD BE SNUG AND NOT OVER-TIGHTENED



10-PIN SUB CONNECTOR



OUTPUT



FOR CLARIFICATION AND ASSISTANCE TO YOUR SPECIFIC APPLICATION, OUR ENGINEERING TEAM WOULD BE GLAD TO ANSWER ALL YOUR QUESTIONS. INFO@NUUT.CA

